

TELEDYNE HASTINGS INSTRUMENTS

INSTRUCTION MANUAL

760 PLUS VACUUM GAUGE



Manual Print History

The print history shown below lists the printing dates of all revisions and addenda created for this manual. The revision level letter increases alphabetically as the manual undergoes subsequent updates. Addenda, which are released between revisions, contain important change information that the user should incorporate immediately into the manual. Addenda are numbered sequentially. When a new revision is created, all addenda associated with the previous revision of the manual are incorporated into the new revision of the manual. Each new revision includes a revised copy of this print history page.

Revision A (Document Number 147-0497)	January 1998
Revision B (Document Number 147-012000)	January 2000
Revision C (Document Number 147-082002)	August 2002
Revision D (Document Number 147-092002)	September 2002
Revision E (Document Number 147-112003)	November 2003
Revision F (Document Number 147-022004)	January 2004
Revision G (Document Number 147-082005)	August 2005
Revision H (Document Number 147-092005)	September 2005

Visit www.teledyne-hi.com for WEEE disposal guidance.

Table of Contents

1.0 GENERAL INFORMATION.....	5
1.1 Features	5
1.2 Specifications	6
2.0 INSTALLATION	7
2.1 Receiving Inspection	7
2.2 Piezo Transducer Installation	7
2.3 Power Supply/Display Installation	8
2.3.1 Power Supply/Display Cables and Wiring	8
3.0 OPERATING INFORMATION	9
3.1 General	9
3.2 Piezo Transducer Input Power	10
3.3 Piezo Transducer Output Signal	10
3.4 Power Supply/Display Input Power	10
3.5 Power Supply/Physical Layout.....	10
3.5.1 Front Panel	10
3.5.2 Rear Panel.....	11
3.6 Power Supply/Relay Setpoints Adjustment	11
3.6.1 Auxiliary Relay Contacts	11
3.7 Pressure Measurements.....	12
4.0 CALIBRATION.....	13
4.1 760 Plus Transducer Zero and Span Adjust	13
4.2 760s Option-05 Transducer Zero and Span Adjust	13
5.0 MAINTENANCE	15
5.1 Power Supply/Display Authorized Maintenance	15
5.2 Piezo Transducer Authorized Maintenance	15
6.0 WARRANTY and REPAIR	17
6.1 Warranty Policy	17
6.2 Non-Warranty Repair Policy	17
7.0 DRAWINGS and SCHEMATICS	19
8.0 INSTALLATION	21

This manual contains technical and general information relating to the installation, operation, and calibration of the Hastings 760 Plus vacuum gauge which is comprised of a piezo vacuum transducer (760s) and power supply/display.

The 760s piezoresistive type transducer has one side of its diaphragm evacuated to a low reference pressure then sealed to produce an absolute pressure signal output. This output signal is linear-proportional to the applied pressure and is independent of gas composition.

The power supply/display provides 24VDC excitation power for the 760s transducer and a four digit dual setpoint meter relay for monitoring, measurement and control applications.

For best performance, this instrument should be operated with the appropriate Hastings accessory items. Attempting to use a Hastings product with other manufacturers equipment may result in damage to all equipment.

1.1 Features

Piezo Vacuum Transducer (760s):

- Linear voltage or current output
- Absolute pressure measurement, independent of gas composition
- Zero and span, adjustable
- Compact size, 1.5" x 1.5" x 3"
- 0.1 - 1000 torr range
- Stand alone operation with 15 - 30VDC input
- All wetted materials 316 stainless steel
- Optional 3-1/2 digit, LCD display

Power Supply/Display:

- Excitation output for use with Hastings 760S piezo vacuum transducer
- 4 1/2-digit high efficiency red LED display
- Two control relays, SPDT, 2 A (max) @ 240VAC (max)
- Relay set point, set manually from front panel
- 120/240VAC input power (no hardware settings required)
- Front panel (SP1, SP2) annunciators (LED'S)
- 1/8 DIN case, panel mounting

1.2 Specifications

Piezo Vacuum Transducer (760s):

Accuracy	$\pm 0.25\%$ FS* (760 Torr)
Operating pressure	1000Torr (nominal)
Maximum over pressure	2300Torr(45 psia)
Operating temperature	0-50°C
Input voltage	15-30VDC
Input power	15 mA @ 24VDC (no load)
Output impedance	1k ohm minimum
Output signal options:	
Option-01	0-1000 Torr @ 0-5 VDC
Option-02 Std.	0-1000 Torr @ 0-10VDC
Option-03	0-1000 Torr @ 2-10 mA
Option-04	0-1000 Torr @ 4-20 mA
Option-05	0-1000 Torr @ 5 or 10VDC w/digital display
Size	1.5" x 1.5" x 2.875"
Wetted material(s)	316 stainless steel

Power Supply/Display:

Digital display	$\pm 0.05\%$ of reading ± 1 digit
Temperature coefficient	< 80 ppm/°C
Input power	120 or 240 volts AC, 50 ma, 50/60 hz
Output power	24VDC nonregulated @ 30 mA
Input signal	0-10VDC (nominal)
Relay(s)	2A @ 240VAC form C
Size	1.9" x 3.8" x 4.6"

* Accuracy 0.25% FS (calibration based on a 0.15% RDG standard)

This section contains the necessary instructions to assist in placing the HPM-760 Plus digital vacuum gauge into operation as quickly and easily as possible. Please read the following thoroughly before attempting to install or use the instrument.

2.1 Receiving Inspection


Carefully unpack the Hastings product(s). Inspect for any obvious signs of damage to the shipment. Immediately advise the carrier who delivered the shipment if any damage is suspected. Check each component shipped with the packing list. Insure that all parts listed are present. Other equipment or accessories will be listed separately.

2.2 Piezo Transducer (760s) Installation

Figure 2-1 shows the Hastings piezo vacuum transducer. A standard 1/8" NPT male stem and evacuation port is provided for system connection. VCR and KF stem terminations are also available

When installing transducers with threaded stem, apply an approved vacuum sealant to the stem threads of the transducer. Hand thread transducer into vacuum system, until joint is finger tight. Tighten transducer module completely using a wrench on the hexagonal portion of the stem.

Do not grip instrument case to tighten; this will result in permanent damage to transducer assembly. When the 760s is purchased independently of the power supply/display, a connector is provided so that the transducer can be connected as detailed in the figure below.



TRANSDUCER PIN OUT

PIN 1	SIGNAL OUTPUT (COM)
PIN 2	SIGNAL OUTPUT (POS)
PIN 3	15-30VDC INPUT (COM)
PIN 4	15-30VDC INPUT (POS)

2.3 Power Supply/Display Installation

Cut a panel opening to the following dimensions; 3.62" (92mm) wide, 1.77" (45mm) tall. Insert the power supply/display through the panel cutout and secure in place using mounting hardware supplied.

2.3.1 Power Supply/Display Cables and Wiring

Three cables provide all wire connections for the Hastings 760 Plus and are shown below:

1. 760 Plus Interconnect Cable





figure 2-1

To power supply/display

Interconnect cable, 4-cond. # 20 A.W.G., 8-ft length standard

2. Power Supply/Display Power Cable



To power supply/display

figure 2-2

AC power cable, 2-cond w/polarized plug., # 18 A.W.G., 8-ft length standard

3.1 General

The piezoresistive transducer is shown schematically in figure 3-1. Basically the membrane contains an ion implanted resistive element that is part of a Wheatstone bridge circuit shown in figure 3-2. The underside of the transducer has been evacuated and sealed to produce a deflection of the membrane the magnitude of which is a function of the differential pressure (ΔP) across the membrane. The resistance of the membrane element changes with that ΔP and thus changes the bridge output.




figure 3-1




figure 3-2

3.2 Piezo Transducer Input Power

The 760s piezo transducer operates with a DC input from 15 to 30 volts. Use the 4-pin female connector supplied and make necessary connections as outlined. See illustration in Section 2 of this manual.

3.3 Piezo Transducer Output Signal

The 760s piezo transducer provides either a linear DC voltage output with pressure or a linear DC current output with pressure. The type of output is determined by the instrument option specified. A brief description of the option, pressure range and output signal is listed below:

OPTION No.	PRESSURE RANGE (Torr)	SIGNAL OUT (see note)
01	0-1000	0-5 VDC
02	0-1000	0-10VDC
03	0-1000	2-10 mA
04	0-1000	4-20 mA
05	0-1000	0-5 or 10VDC w/LCD digital display

NOTE: The 760 Plus power supply/ display or the 760s option-05, provide a direct pressure readout in Torr units.

3.4 Power Supply/Display Input Power

The 760 Plus power supply/display must be connected to a source of AC voltage, either 120 or 240V, before attempting to program or setup the unit for operation with the Hastings 760S piezo vacuum transducer (see Section 2.3 for cable description).

3.5 THPS-760 Power Supply Physical Layout

3.5.1 Front Panel (Refer to page 19, 7.1.1 for physical layout.)

Digital Display. The THPS-760 has a 4 1/2-digit display that displays continuous readout.

Set Point Adjustment Pots.

Two Set Point Adjustment Pots are accessible on the panel and are used to set the desired set points. (SP1/SP2) Refer to SET POINT ADJUSTMENTS and figure 1 for specific instructions pertaining to setting the set points.

THE KNOBS ON THE SET POINT ADJUSTMENT POTS ARE PERMANENTLY INSTALLED AND CAN NOT BE REMOVED. REMOVING THEM COULD CAUSE PERMANENT DAMAGE TO THE SET POINT POTS.

Set Point Pushbuttons.

There are two set point pushbuttons (SP1 AND SP2) accessible on the front panel. When depressed, the setpoint value is displayed on the LED readout

SET POINT LED's. The two LED indicators (SP1 and SP2) will illuminate when the input pressure is less than desired (SP1/SP2) set point. The LED's indicate the corresponding relay is activated (energized).

3.5.2 Rear Panel

Refer to page 19, 7.1.2 for rear view and specific pin outs and connector arrangements.

AC Input Connector J1

Universal input power 110vac to 220 vac. No hardware settings required.

J3 Input/Output Connector

Sensor Input (pin 9) Input signal from HPM 760S sensor
Sensor Ground (pin 10) Input ground

Signal output (pin 12) Auxiliary signal output. (0 to +10vdc)
Signal output return (pin 11) Auxiliary signal return

24vdc Output (pin 7) 24vdc Auxiliary output
24vdc Return (pin 8) 24vcd Auxiliary return

SP1 relay contacts (pins 1,2,3) SP1 relay SPDT contacts. (max)2 amps @ 250vac
SP2 relay contacts (pins 4,5,6) SP2 relay SPDT contacts. (max)2amps @ 250vac
(Either relay will energize when input pressure is less than desired set point).

Grounding Considerations

If the THPS-760 is being used in an area with excessive electromagnetic interference (EMI), the power supply may need to be grounded. This is accomplished by attaching one end of a grounding wire to the Thumbscrew located at the rear of the THPS 760. The other end should be connected to the 760 sensor ground. A shielded cable may be utilized.

3.6 Power Supply Relay Set Point Adjustment

The THPS-760 Power Supply has two separate set points with corresponding LED Indicators and relay contact outputs. Each Relay has option of either normally open or Normally Closed contacts.

1. Ensure 120vac/220vac is supplied to HPS-760 Power Supply. (No switching necessary.)
2. SP1 setting. Depress SP1 set point switch and hold.
 - (a) Turn the SP1 Potentiometer until the desired set point is displayed on digital display.
 - (b) Release switch.
3. SP2 setting. Depress SP2 set point switch and hold.
 - (a) Turn the SP2 Set Point Potentiometer until the desired set point is displayed on digital display.
 - (b) Release switch.
4. With both set point push buttons switches released the digital display will indicate input from HPM-760 sensor. **The SP1/SP2 set point relays will energize when the input is less than the SP1/SP2 set point. Depressing both set point switches at the same time will result in an erroneous reading, but will not affect the proper operation of the unit.**

Auxiliary Relay Contacts

The THPS-760 Power Supply has SP1 and SP2 relays for various external switching/monitoring applications. Each relay has a single set of Form "C" contacts. (Choice of normally open or normally closed contacts). The relays will energize (pick up) when the input is less than the preset set points as adjusted in the Set Point Adjustment procedures above. The set point LED Indicators (SP1 or SP2) will illuminate indicating that (SP1 or SP2) relay is energized. The choice of the normally open or normally closed contacts will depend on the desired switching function of the particular application. Each set of contacts is capable of switching up to 2 amps (max) @ 250 vac .

3.7 Pressure Measurements

The 760 Plus piezo transducers are shipped from the factory fully calibrated; thus, can provide immediate and accurate pressure measurements as soon as the installation outlined in Section 2.2 has been completed. If using a 760 Plus power supply/display, the pressure can be read directly in Torr units. When not using a 760 Plus power supply/display, the linear output voltage or current depending on option, must be interpolated to obtain absolute pressure measurements.

Figure 3-3 on the following page of this manual shows a typical signal output vs pressure curve. Note the excellent linearity over 4-decades of pressure.

The Hastings 760 Plus power supply/display is calibrated at the factory prior to shipment and does not require adjustment when installed. The user should not attempt to calibrate the Hastings 760 Plus power supply/display; however, if the display indication is incorrect, calibrate the Hastings piezo transducer by adjusting the ZERO and SPAN controls as outlined in this manual.

The Hastings transducer can be adjusted by performing the following procedure. If you intend to use this procedure, you will need a vacuum system capable of achieving base pressures below 1.00E-02 Torr, and a power supply/display which is calibrated for the option in use.




figure 3-3

**Signal output Voltage -vs- Pressure
(760s option-01 (0-5VDC) transducer)**

4.1 Hastings 760 Plus Piezo Transducer Zero and Span Adjustment

1. Install the transducer and power supply/display then apply operating power. Wait a minimum of 15 minutes before proceeding.
2. Evacuate system to a pressure less than 0.010 Torr ($1.00\text{E-}02$ Torr).
3. Adjust transducer zero trimpot (Fig. 2-1) until the power supply/display indicates 000.0 ± 000.1 Torr.
4. Increase system pressure to atmosphere and adjust span trimpot until the power supply/display indicates the known local atmospheric pressure ± 000.1 Torr.
5. Repeat steps 2 through 4 if necessary.

4.2 Hastings 760s Option-5 Transducer Zero and Span Adjustment

1. Install the transducer and apply operating power. Wait a minimum of 15 minutes before proceeding.
2. Evacuate the system to a pressure less than 0.01 Torr ($1.00\text{E-}02$ Torr).
3. Adjust transducer zero trimpot (Fig. 2-1) until display indicates 000 ± 001 Torr.
4. Increase system pressure to atmosphere and adjust span trimpot (Fig. 2-1) until display indicates the known local atmospheric pressure ± 001 Torr.
5. Repeat steps 2 through 4 if necessary.

5.1 Power Supply/Display Authorized Maintenance

During normal operation and excluding the calibration procedure, Hastings 760 Plus power supply/display does not require maintenance. In the event a Hastings power supply/display fails or is otherwise damaged, it should be returned to the manufacturer (factory) for repair or replacement after first obtaining the necessary returned material authorization (RMA) number.

5.2 Piezo Transducer Authorized Maintenance

During normal operation and excluding the calibration procedure, Hastings piezo vacuum transducers (760S) do not require maintenance or adjustment. In the event a transducer fails or is otherwise damaged, it should be returned to the manufacturer (factory) for repair or replacement after first obtaining the necessary returned material authorization (RMA) number.

Warranty and Repair

6.1 Warranty Repair Policy

Hastings Instruments warrants this product for a period of one year from the date of shipment to be free from defects in material and workmanship. This warranty does not apply to defects or failures resulting from unauthorized modification, misuse or mishandling of the product. This warranty does not apply to batteries or other expendable parts, nor to damage caused by leaking batteries or any similar occurrence. This warranty does not apply to any instrument which has had a tamper seal removed or broken.

This warranty is in lieu of all other warranties, expressed or implied, including any implied warranty as to fitness for a particular use. Hastings Instruments shall not be liable for any indirect or consequential damages.

Hastings Instruments, will, at its option, repair, replace or refund the selling price of the product if Hastings Instruments determines, in good faith, that it is defective in materials or workmanship during the warranty period. Defective instruments should be returned to Hastings Instruments, **shipment prepaid**, together with a written statement of the problem and a Return Material Authorization (RMA) number. Please consult the factory for your RMA number before returning any product for repair. Collect freight will not be accepted.

6.2 Non-Warranty Repair Policy

Any product returned for a non-warranty repair must be accompanied by a purchase order, RMA form and a written description of the problem with the instrument. If the repair cost is higher, you will be contacted for authorization before we proceed with any repairs. If you then choose not to have the product repaired, a minimum will be charged to cover the processing and inspection. Please consult the factory for your RMA number before returning any product repair.

TELEDYNE HASTINGS INSTRUMENTS

804 NEWCOMBE AVENUE

HAMPTON, VIRGINIA 23669 U.S.A.

ATTENTION: REPAIR DEPARTMENT

TELEPHONE (757) 723-6531


1-800-950-2468

FAX (757) 723-3925

E MAIL hastings_instruments@teledyne.com


INTERNET ADDRESS <http://www.hastings-inst.com>

Repair Forms may be obtained from the "Information Request" section of the Hastings Instruments web site.



7.1.1 Front Panel

The THPS-760 has a 4 1/2-digit display that displays continuous readout.




7.1.2 Rear Panel

Decal is to be black ink printed on silver compucal, with adhesive on the back

7.1 Mounting

Cut out panel as shown in the diagram below.



7.1.2 Panel Mounting

- 1) Slide power supply into panel from the top.
- 2) Attach brackets to the side of the power supply.
- 3) Tighten screws against panel.

